

Lazer Star Lights • 2734 Danley Court, Paso Robles, CA • 805.226.8200 • Jazerstarlights.com

Part Numbers: 77130401 – 77235003 (except PN: 77132005)
Dominator LED Light Bar Wiring Instructions

GENERAL NOTES:


* These instructions are also available on our website: lazerstarlights.com. Please check our website before you begin installation for any updated instructions as well as additional photos for your reference.

PARTS LIST:

* (1) Complete Wire Harness

<u>APPROXIMATE INSTALL TIME:</u> 10 min – 20 min

INSTALLATION:



Page 1 of 2

Dominator LED Light Bar Instructions (PN: 77130401 – 7725003; except PN: 77132005)

Lazer Star Lights 2734 Danley Court, Paso Robles CA 93446 • 805.226.8200 <u>lazerstarlights.com</u>

- A) Relay
- B) Lighted On Switch
- C) Main Ground Lead
- D) Main Power Lead
- E) 30 Amp Fuse
- F) Deutsch Connector
- 1. Disconnect negative (-) battery terminal.
- 2. Mount Relay (Part A) to secure location away from hot or moving parts.
- 3. Route the 30 Amp Fuse (Part E) to battery and secure wire away from any hot or moving parts.
- 4. Route switch (Part B) to inside of vehicle.
 - a. Switch has 3M tape on the back Make sure that the selected area is clean, oil free, and dry prior to sticking switch to desired surface.
- 5. Connect Main Power Lead (Part D) to positive (+) battery terminal.
- 6. Connect Main Ground Lead (Part C) to negative (-) battery terminal.
- 7. Connect Deutsch Connector (Part F) to light.
 - a. Please note the original wire lead is no longer needed.
- 8. Reconnect negative (-) battery terminal.
- 9. Test light and switch power.

Installation is Complete

Use and Care Tips:

- * Keep all wires away from hot or moving parts.
- * Always disconnect the battery when working with wiring.
- * Periodically check connections and bolts to make sure they are tight.