



LX LED Headlight Capsule Upgrades

Installation Instructions



1. Unplug the pre-existing headlight capsule; this may require the removal of a rubber or plastic cover.
2. Remove the pre-existing headlight bulb from the light socket by turning counterclockwise.
3. Install your LX LED Headlight Capsule by inserting it and turning clockwise.
 - When the capsule is installed correctly, the wire coming out of the back should be at the bottom of the light (in the 6 o'clock position).
4. Plug the end of the LX LED Headlight capsule into the power socket.
5. Re-install any removed dust covers.
6. Route any wires away from hot or moving parts.

Installation is Complete.

Notes

- Depending on the vehicle YMM, flickering or pulsing of the light may occur. If flickering/pulsing does occur, please contact Lazer Star Lights for necessary additional decoder.
- While every effort is made for fitment on all vehicles Year/Make/Model, we cannot test fitment on every one. Correct fitment may require some modification or may not fit your specific vehicle. Only undamaged items can be returned.

Warning

- Always turn off vehicle's engine and read installation instructions prior to beginning installation.
- We recommend wearing gloves when handling any wires, removing or replacing pieces, or general handling of Lazer Star Lights products.
- Make sure that the vehicle voltage complies with this product.
- Do not look directly at the light when on.
- Do not touch the LED with your bare hands.

