




LX LED H4/H7 Headlight Capsule Upgrades

Installation Instructions



1. Unplug the pre-existing headlight capsule and remove the dust cover.
2. Remove the pre-existing headlight bulb from the light socket.
3. Remove the LX LED Headlight Capsule from its mounting base by turning the capsule counterclockwise from the base.
4. Install the base into the reflector and secure it with the pre-existing clip.
5. Re-install the dust cover.
6. Install the LX LED Headlight Capsule into its base by inserting it and turning clockwise.
 - When the capsule is installed correctly, the wire coming out of the back should be at the bottom of the light (in the 6 o'clock position).
7. Plug the end of the LX LED Headlight capsule into the power socket.
8. Route any wires away from hot or moving parts.

Installation is Complete.

Notes

- Depending on the vehicle YMM, flickering or pulsing of the light may occur. If flickering/pulsing does occur, please contact Lazer Star Lights for necessary additional decoder.
- While every effort is made for fitment on all vehicles Year/Make/Model, we cannot test fitment on every one. Correct fitment may require some modification or may not fit your specific vehicle. Only undamaged items can be returned.

Warning

- Always turn off vehicle's engine and read installation instructions prior to beginning installation.
- We recommend wearing gloves when handling any wires, removing or replacing pieces, or general handling of Lazer Star Lights products.
- Make sure that the vehicle voltage complies with this product.
- Do not look directly at the light when on.
- Do not touch the LED with your bare hands.

