


Prerunner Wire Harness



- A) Relay: To be mounted away from hot or moving parts.
- B) 30 AMP Fuse:
- C) Keyed Power: To be connected to any circuit that is powered only when the key is on. This will prevent lights from being left on accidentally.
- D) Toggle Switch: To turn lights on and off.
- E) Ground: To be grounded to the body.
- F) Duesch Connector: To be connected to light.
- G) Main Power: To be connected to positive terminal of battery.
- H) 30 AMP Fuse:
- I) Ground: To be connected to negative terminal of battery.