



INSTALLATION TIPS

LAZER STAR BANSHEE MOUNTING BRACKET

If you have purchased stock location mounting brackets skip to #2.
The instructions below are if you have no brackets.

1. We recommend that you remove the stock mounting bracket and install your LAZER STAR'S in the top of the shock tower. You can do this by chiseling the spot weld on the stock bracket and drilling a 3/8" dia. hole in the shock tower.

Bracket Installation:

2. a. Retain the bolt that held on your original lights.
b. Start by removing all but 1 nut and 1 flat washer from the threaded stud on the lights.
c. Run the wires into the threaded hole on the bracket and thread the light into the bracket about 3-4 turns.
d. Being careful not to pinch the wires, slide the new bracket over the outside tab until the threaded hole passes it. Once the bracket is on far enough, thread the light all the way into the bracket.
e. Insert the original bolt into the outside hole on the new bracket through the outside tab. Then use one of the sleeves provided and slide it over the bolt in between the stock tabs then thread the bolt into the inner stock tab.
f. Tighten the mounting bolt, threaded stud and cross bolt on the light. The threaded stud should be fairly tight, do not over tighten the cross bolt on the light. You should still be able to move the light when you're done.
3. There are two wires coming out of the lights one goes to your common or "ground" slot on the plug, and one goes to your HIGH BEAM slot on your plug. It does not matter which wire is the ground and which is the hot.
4. Be sure that your LAZER STAR'S are securely mounted and that nothing is touching them so as not to blemish the finish.
5. When all is working correctly the lights should be off in the 'off' and the 'low' position and should be on in the 'high' position.

If you have any questions or comments please feel free to give us a call at 800.624.6234, or you can fax us at 805.226.8150

**THANK YOU FOR CHOOSING
Lazer Star Lights!**

2734 Danley Court, Paso Robles, CA 93446
800-624-6234 • 805-226-8200 • f. 805-226-8150
info@lazerstarlights.com • lazerstarlights.com