



INSTALLATION TIPS

LAZER STAR TAILLIGHT CONVERTER

**FOUR USE WITH 2 HALOGEN OR LED LIGHTS MAXIMUM.
50 WATTS MAXIMUM PER LIGHT.**

1. If you have existing taillights that you are replacing, remove them. Be sure to leave enough wire to work with.
2. Mount your new Lazer Star Lights so that the body is not touching anything, foreign objects touching your light may damage it.
3. You are using the light as a “dual element” light you will need a Lazer Star Taillight Converter 2 (P.N.: LSWC808).
4. Find a location somewhere along your existing wiring to mount your converters. Nothing else should come in contact with the converters.
 5. Wire the converter to your wires.
 - a. Connect the GRAY wire to the LEFT turn signal.
 - b. Connect the YELLOW wire to the RIGHT turn signal
- Note: (Either one of the white or black on halogen & the red or the yellow on LED).
 - c. Connect the PURPLE wire to the LEFT turn wire from the vehicle
 - d. Connect the BROWN wire to the RIGHT turn wire from the vehicle
 - e. Connect the BLUE wire to a keyed power source (running light wire OK)
 - f. Connect the BLACK wire to ground (-)
6. Wire your Light. HALOGEN: Take 1 wire (doesn't matter which one) from the light and connect it to the corresponding wire from the converter. The other wire from the light is the ground. You may ground it near the light or hook it to the now unused ground wire that ran to your old light. LED: Take the RED (red LED) or Yellow (Amber LED) etc. and connect it to the corresponding wire from the converter. The black wire is ground.

If you need further assistance or have any questions regarding the use or installation of your lights please give us a call at 805-226-8200. See “Installation Tips and Care” sheet included with your lights for further information as well as Warranty information.

If you have any questions or comments please feel free to give us a call at 800.624.6234
Or you can fax us at 805.226.8150

**THANK YOU FOR CHOOSING
Lazer Star Lights!**

2734 Danley Court, Paso Robles, CA 93446
800-624-6234 • 805-226-8200 • f. 805-226-8150
info@lazerstarlights.com • lazerstarlights.com